

TX
RX
Wireless
Ren-W
Wireless
Ren-W
PC
TX
RS232/USB
RS485
Adapter
Omit if Wireless
Ch1
Simple Renard
Strobe Burst Controller
RX
+12V
GND
TX
Ch16
12 Volt DC Power Supply
Strobe Burst Modules
Each Module has 3 connections
+12 volts, GND and a Control signal
RS485
RX
Renard Controller
TX
RS485
RX
Renard Controller
TX
Strobe Burst Modules